

# Pikestuff Assembly for H0 Scale

## Roof Cut Lines

Remove flash around the notch.

Roof Ridge goes in the center between the roofs  
Note: Notch faces out. This leaves room for the walls to sit.

Bottom view of roof panels  
& roof ridges

Note: Raised ridge goes out

Cut glue strips and glue over joints

Once the cuts are made if needed glue the roof panels and roof ridges together. See below for more details. Cut glue strips and place over joints to strengthen joints. Cut the glue strips so they don't go to the edge of the roof. Leave a little room for the walls to sit.

Cut lines are provided on the back side of the roofs. Depending on the kit you have you may or may not need to cut the roofs to a different size.


Note: Raised ridge goes out

Cut glue strips and glue over joints

30 foot buildings  
50 foot buildings  
Full length 70 foot buildings

Roof Ridge goes in the center between the roofs. Note: Notch faces out

Top view of the roof ridge & roof panels. The roof ridge goes in the center and between the roof panels as shown.



Set the roof panels on each side of the roof ridge as shown. Note that the roof ridge has the correct angle for the roof pitch when glued. It's not flat.

